

Installation instructions for *The Jon* and *The Loo*

Note: when installing your new Jon/Loo, always replace your old wax ring. →



Use Side access holes to aid in toilet alignment on closest fitting studs. →



Once toilet is secure install supplied access hole covers. →



Install water supply line from home to toilet inlet fitting (supply line not included) →



Remove toilet tank cover. Turn on water supply and let the toilet tank fill completely. Water level should be 1/4" - 1/2" from bottom of fan assembly.

To adjust height, move fan assembly up or down in take to designated height. (See Photo) →

Improper height will result in a gurgle sound.



Toilet flush adjustments can be made by adjustment of set screws up or down. Apply teflon tape and secure lock nut. Correct adjustment of 1/16" - 1/8" from plunger. (see photo)



Loosely Install Toilet seat mounts without chrome covers. Temporarily install toilet seat. →

Align seat with front and sides of toilet. Then secure mounting bolts.



Remove seat by depressing both side buttons on quick release toilet.

Install chrome covers and reinstall seat. (Our Quick release seat dramatically improves the ability to clean toilet seat area vs traditional seat mounts)

Plug in the Jon/Loo and enjoy clean air and power savings with your new ecoair

Just a reminder: Ecoair odorless toilet systems require a 15-amp GFI outlet 9"-20" from center of toilet.

