

Remote Control Programming for *The Throne*

Programming lid speed:

- Push the lid button and the seat button simultaneously.
- You will hear 1 beep followed by a series of 1-5 beeps.
- After you have depressed the button and hear the number of beeps let off buttons and repeat these steps till you hear 1 beep followed by 4-5 beeps. *This setting appears to be the most popular with our users!*
 - 1 beep - lowest (seat will open and close immediately) *Should be the default setting.*
 - 2-5 increase the speed 5 being the fastest.

Programming lid opening distance:

- Hold light button until you hear 2 beeps.
- Remove finger from button and press the left directional in increments of 10 after pressing the left arrow the recommended 10 times.
- Tap the light bulb icon so it beeps once. This locks in the program.
- Repeat these steps until the desired 90 deg angle is achieved.

Programming Seat speed:

- Hold the power savings button and the lid button simultaneously.
- This will activate the program mode indicated by 1 beep followed by 1-3 beeps.
- After you hear the one beep keep track of the following beeps and release the two buttons.
- Repeat these steps till the desired open/close speed is achieved.
 - 1 - slowest
 - 2-3 faster

Setting 2 seems to be popular with most users!